



904-12 Metal Window Snaplock Fitting Instructions

Installing a Metal Window Snaplock

To fit a Metal Window Snaplock you will require the following tools:

- Drill
- 3.5mm drillbit
- Screwdriver
- Pencil

- A** Close window and select position of Metal Window Snaplock(s).
- B** Position striker plate on fixed frame with location lug against edge of fixed frame. Mark hole positions. Apply masking tape to drill bit and drill holes to a 4mm depth.

Caution: Ensure that the drill depth does not touch the glass. Screw the striker plate into position with the shorter (6mm) screws.

- C** Position the lock mechanism on the fixed frame ensuring striker plate snaps into the lock mechanism centrally, then mark the screw holes.
- D** Drill holes in fixed frame and screw lock mechanism to the frame with the longer (10mm) screws. Check lock operation. Insert plastic plugs into the lock mechanism screw holes.

Additional Information

Operation - Locks automatically when closing window. Turn key clockwise to open.

Security Tips - We recommend fitting locks to all hinged windows (even small top hinged windows) for extra security.

